Η Daudoor R Building the Fiture, Restoring the Past...





BAU100



BAU**100**



BAU100



BAU100



BAU**100**

BAU101









BAU**300**



BAU**300**









BAU**301**



BAU**301**



BAU301



BAU**301**









BAU**330**



BAU**330**







BAU**331**



BAU**331**



BAU331

BAU**351**



BAU**331**









BAU**410**

BAU**411**

Ŷ

ī٢

WATER RESISTANT RESISTANT TO IMPACTS BAU**410**

BAU**411**

ANTI- RESISTANT PAINT AND B1 BACTERIAL TO MOISTURE MAINTENANCE FIREPROOF ARE NOT REQUIRED

ĺ

BAU**410**

BAU412













BAU2000 **ARGENTO MIX**



BAU2000 WHITE **TEAK MIX**



BAU**2000** TEAK MIX





BAU2100 MILANO WALNUT MIX



BAU1134



BAU1134



BAU1132



BAU1132





BAU1122-R



BAU1103-R















BAU3000



BAU**3000**



BAU3000













BAU**3000**



BAU**3000**



BAU3003



BAU3003







BAU**3122-R**

BAU**3122-R**

0



BAU3122-R







BAU**3122-R**



BAU**3122-R**



WATER RESISTANT PAINT AND RESISTANT TO IMPACTS MAINTENANCE ARE NOT REQUIRED







BAU**3202-3**



BAU**3203-3**











BAU**3220**



BAU3220-3

ī Ċ WATER RESISTANT RESISTANT PAINT AND TO IMPACTS MAINTENANCE ARE NOT REQUIRED



BAU3223-3



BAU3230-3







BAU3380



BAU3386



BAU3268





BAU3286



BAU3310







BAU3310-3



BAU3330-3



BAU3430-34





BAU3430-85













BAU7060



BAU7060



BAU**7061**



BAU**7400**



BAU**7400**





PROJECT PRODUCTS



BAU7020



BAU**7020**



BAU**7020**



BAU**7023**



BAU7024



BAU**7024**



WATER RESISTANT PAINTAND RESISTANT TO IMPACTS MAINTENANCE ARE NOT REQUIRED ML. WHITE MAGIC MAGIC WAGIC WHITE SN GREY WHITE MAPLE SAHRA STONE VISON BAMBOO

PROJECT PRODUCTS

5.

BAU**7040**



BAU**7040**

CEDRUS SERIES



BAU**7040**



BAU**7044**



BAU**7044**





PROJECT PRODUCTS BAU7059 BAU7059 BAU7059



BAU**7750**

BAU7750




Note: Gold Walnut color is just available for 7750 model.








TECHNICAL SPECIFICATION






| SASH MEASUREMENT | FRAME OUTER MEASUREMENT | 70mm CORNICEOUTER MEASUREMENT | 100mm CORNICEOUTER MEASUREMENT |
|---------------------|----------------------------|-------------------------------------|--------------------------------------|
| F | Н | G | G |
| 2030 | 2073 | 2133 | 2163 |




SASH WIDTH MEASUREMENT

| SASH MEASUREMENT | FRAME OUTER MEASUREMENT | 70mm CORNICEOUTER MEASUREMENT | 100mm CORNICEOUTER MEASUREMENT |
|---------------------|----------------------------|-------------------------------------|--------------------------------------|
| А | С | E | E |
| 650 | 705 | 825 | 855 |
| 700 | 755 | 875 | 905 |
| 750 | 805 | 925 | 955 |
| 800 | 855 | 975 | 1005 |
| 850 | 905 | 1025 | 1055 |
| 900 | 955 | 1075 | 1105 |



Adokapı may change these technical specifications.

TECHNICAL SPECIFICATION



- Composite material.


- Not affected by water and moisture.

Decorative Top Cornice

35

In Fagus and Cedrus ranges, water and moisture resistance are valid only for frames and cornice. Adokapı products are interior doors. If they are used outdoors, factory warranty is not provided.

DOOR ASSEMBLY



Frame edge jointing apparatuses are fitted as shown in the figure and their edges are jointed.



Hinges are screwed to the leaf with the upper hinge center 250 mm and lower hinge center 300 mm.



Apply polyurethane foam in the gap between the frame and wall. After drying, remove the foam residues.



Double-side adjusted cornice are cut according to the measurement and fitted by using a plastic hammer.

OUR ASSEMBLY MATERIALS

Sashe - Cornice- Hinge - Screws- Lock



The frame is placed in the wall gap in the middle. Squeezing pins are placed in the upper and side gaps and fixed by adjusting with the measurement gauge.



Upper hinge center is screwed to the frame as 254 mm from above.



Lock is screwed to the drilled area in the frame.



For Deodara range doors, ADOKAPI label is screwed on the lower and upper edge of the leaf as shown in the figure.



Adjust the internal measurement between sashe and frame as 3.5 mm by using an adjuster. Frame - Sashe balance should be checked again.



Lock and handle suitable for the leaf are fitted by screwing them.

STACKING CONDITIONS

- 1- Pallet packaging of the door components that will be kept in the stocks should not be opened unless needed.
- 2- Stacking floor should be flat and levelled.

3- Stacks should be supported in the horizontal position with minimum 3 wedges. They should not be stacked vertically even in the construction sites.

4- Ensure that the wedges to be used for stacking have equal sizes and are not twisted.

5- Wedges should be placed in between the stacks to be placed on top of each other at the same level of the wedges on the floor.

6- Base pallet should be placed on top of the door leaves that will not be removed for a long time.

7- Products should not be stacked in the warehouses with insufficient ventilation and air-conditioning (ensure 22-24 degrees and 8-12% balance moisture).

8- Make sure that the products are not exposed to direct sunlight, wind and water.

9- Protect the products against any damages that might occur due to the use of forklift for loading and unloading.

CONTACTS

Balkans

Address: Magistralni put 246, Industrijska zona Maline, 75270, Živinice, Bosnia/Herzegovina Tel: +387 35808555 | **E-Mail:** info@baufit.ba

audoor

www.baufit.com

Europe

Address: 41 Avenue grand clement.69120 Vaulx en velin/LYON Tel: +33 7 50 99 64 54 | E-Mail: msarikaya@baufit.com

Asia & Middle East

Address: Konak Mah. Lefkose Cad. Baris Sok. Ofis + Plaza No:3 Kat:1 Daire no: 12 PK: 16265 Nilufer/Bursa/ Turkey Tel: +90 224 205 0474 | E-Mail: info@baufit.com

South East Asia

Baufit Asia Co. Ltd

Address: 321/1 Phatthanakan Rd, Khwaeng Prawet, Khet Prawet, Krung Thep Maha Nakhon 10250,Thailand Tel: +66 2 101 2799 | E-Mail: support@baufitasia.com | Sales: sales@baufitasia.com